



IMPORTANT INFORMATION


Section 1C - General Information

Table of Contents

Serial Number Location	1C-1	Submerged While Running	1C-5
Conditions Affecting Performance	1C-2	Fresh Water Submersion	1C-5
Weather	1C-2	Model 240 HP Front View	1C-7
Boat	1C-2	Model 240 HP Starboard View	1C-8
Engine	1C-3	Model 240 HP Port View	1C-9
Engine Compression	1C-4	Model 240 HP Aft View	1C-10
Water Pressure Check	1C-5	Model 240 HP Top View	1C-11
Following Complete Submersion	1C-5	Mercury Jet Pump Starboard View	1C-12
Salt Water Submersion	1C-5	Mercury Jet Pump Port View	1C-12

Serial Number Location

A serial number decal is located on the side of the flywheel cover and on top of the cylinder block.




a - Engine Serial Number
b - Model Year

c - Year Manufactured
d - Pump Serial Number

IMPORTANT: The Pump Unit Serial Number sticker must be taken out of the envelope affixed to the pump unit and applied to decal on air intake.



The engine serial number and pump serial number are different and unique. The engine serial number is located on top of cylinder block. The pump unit serial number is stamped in a plug located above the shift cable hole on the starboard side of the pump housing.



a - Pump Unit Serial Number

59212

Conditions Affecting Performance

Weather

It is a known fact that weather conditions exert a profound effect on power output of internal combustion engines. Therefore, established horsepower ratings refer to the power that the engine will produce at its rated RPM under a specific combination of weather conditions.

Corporations internationally have settled on adoption of I.S.O. (International Standards Organization) engine test standards as set forth in I.S.O. 3046, standardizing the computation of horsepower from data obtained on the dynamometer. All values are corrected to the power that the engine will produce at sea level, at 30% relative humidity, at 77° F (25° C) temperature and a barometric pressure of 29.61 inches of mercury.

Summer conditions of high temperature, low barometric pressure and high humidity all combine to reduce the engine power. This, in turn, is reflected in decreased boat speeds--as much as 2 or 3 miles-per-hour (3 or 5 km per hour) in some cases. Nothing will regain this speed for the boater, but the coming of cool, dry weather.

In pointing out the practical consequences of weather effects, an engine running on a hot, humid, summer day may encounter a loss of as much as 14% of the horsepower it would produce on a dry, brisk spring or fall day. The horsepower that any internal combustion engine produces depends upon the density of the air that it consumes and in turn, this density is dependent upon the temperature of the air, its barometric pressure and water vapor (or humidity) content.

Boat

WEIGHT DISTRIBUTION

1. Proper positioning of the weight inside the boat (persons and gear) has a significant effect on the boat's performance, for example:
 - a. Shifting weight to the rear (stern)



- (1.) Generally increases top speed.
 - (2.) If in excess, can cause the boat to porpoise.
 - (3.) Can make the bow bounce excessively in choppy water.
 - (4.) Will increase the danger of the following wave splashing into the boat when coming off plane.
- b. Shifting weight to the front (bow)
 - (1.) Improves ease of planing off.
 - (2.) Generally improves rough water ride.
 - (3.) If excessive, can make the boat veer back-and-forth (bow steer).

BOTTOM

1. **Boat Bottom:** For maximum speed, a boat bottom should be nearly a flat plane where it contacts the water and particularly straight and smooth in fore-and-aft direction.
 - a. **Hook:** Exists when bottom is concave in fore-and-aft direction when viewed from the side. When boat is planing, “hook” causes more lift on bottom near transom and allows bow to drop, thus greatly increasing wetted surface and reducing boat speed. “Hook” frequently is caused by supporting boat too far ahead of transom while hauling on a trailer or during storage.
 - b. **Rocker:** The reverse of hook and much less common. “Rocker” exists if bottom is convex in fore-and-aft direction when viewed from the side, and boat has strong tendency to porpoise.
 - c. **Surface Roughness:** Moss, barnacles, etc., on boat or corrosion of motor’s gear housing increases skin friction and cause speed loss. Clean surfaces when necessary.
 - d. **Jet Unit:** If unit is left in the water, marine vegetation may accumulate over a period of time. This growth **MUST** be removed from unit before operation, as it may clog the water inlet holes in the gear housing and cause the engine to overheat.

WATER ABSORPTION

It is imperative that all through hull fasteners be coated with a quality marine sealer at time of installation. Water intrusion into the transom core and/or inner hull will result in additional boat weight (reduced boat performance), hull decay and eventual structural failure.

CAVITATION

Cavitation is caused by water vapor bubbles forming either from sharp turns or from an irregularity in the impeller blade itself. These vapor bubbles flow back and collapse when striking the surface of the impeller blade resulting in the erosion of the impeller blade surface. If allowed to continue, eventual blade failure (breakage) will occur.

VENTILATION

Ventilation occurs when air is drawn from the water’s surface or from the engine exhaust flow (in reverse) into the impeller blades. These air bubbles strike the impeller blade surface and cause erosion of the blade surface. If allowed to continue, eventual blade failure (breakage) will occur.

Engine

DETONATION

Detonation in a 2-cycle engine resembles the “pinging” heard in an automobile engine. It can be described as a “rattling” or “plinking” sound.




Detonation generally is thought of as spontaneous ignition, but it is best described as a noisy explosion in an unburned portion of the fuel/air charge after the spark plug has fired. Detonation creates severe, untimely shock waves in the engine and these shock waves often find or create a weakness: the dome of a piston, piston rings or piston ring lands, piston pin and roller bearings. <http://motorka.org>

While there are many causes for detonation in a 2-cycle engine emphasis is placed on those causes which are most common in marine 2-cycle application. A few which are not commonly understood are:

1. Over-advanced ignition timing.
2. Use of low octane gasoline.
3. Lean fuel mixture at or near wide open throttle.
4. Spark plugs (heat range too hot, incorrect reach, cross-firing).
5. Inadequate engine cooling (deteriorated cooling system).
6. Combustion chamber/piston deposits (result in higher compression ratio).

Detonation usually can be prevented provided that (1) the engine is correctly set up and (2) diligent maintenance is applied to combat the preceding detonation causes listed.



51115

Damaged Piston Resulting from Detonation

Engine Compression

1. Remove spark plugs.
2. Install compression gauge in spark plug hole.
3. Hold throttle plate at W.O.T.
4. Crank engine through at least four compression strokes to obtain highest possible reading.
5. Check and record compression of each cylinder. Variation of more than 15 psi (103.5 kPa) between cylinders indicates that lower compression cylinder is in some way defective such as worn or sticking piston rings and/or scored piston and cylinder.
6. Compression check is important because an engine with low or uneven compression cannot be tuned successfully to give peak performance. It is essential, therefore, that improper compression be corrected before proceeding with an engine tune-up.
7. Cylinder scoring: if powerhead shows any indication of overheating, such as discolored or scorched paint, visually inspect cylinders for scoring or other damage as outlined in Section 4: **Powerhead**.



Water Pressure Check

Water pressure may be checked by using a Digital Diagnostic Terminal (91-823686A2), or if the boat is so equipped, with a Mercury Monitor or Smartcraft Gauges.

RPM	Water Pressure PSI (kPa)
1,000 - 1,100 (in Neutral)	1/2 - 1-1/2 (3.4 - 10.0)
5300 (Boat on Plane)	10 - 15 (69 - 103)
6000 (Boat on Plane)	13 - 17 (90 - 117)

Following Complete Submersion

Submerged engine treatment is divided into three distinct problem areas. The most critical is submersion in salt water, the second is submersion while running, the third is submerged in fresh water.

Salt Water Submersion

Due to the corrosive effect of salt water on internal engine components complete disassembly is necessary before any attempt is made to start the engine.

Submerged While Running

When an engine is submerged while running, the possibility of internal engine damage is greatly increased. If, after engine is recovered and with spark plugs removed, engine fails to rotate freely when turning flywheel, the possibility of internal damage (bent connecting rod and/or bent crankshaft) exists. If this is the case, the powerhead must be disassembled.

Fresh Water Submersion


IMPORTANT: Engine should be run within 2 hours after recovery, or serious internal damage may occur. If unable to start engine in this period, disassemble engine and clean all parts. Apply oil as soon as possible.

NOTE: *If sand has entered the air intake on the engine, do not attempt to the start the engine. Sand will cause internal engine damage. Disassembly is required to clean all internal engine components of sand.*

1. Recover engine from water as quickly as possible.
2. Clean the exterior of powerhead with fresh water.
3. Dry all wiring and electrical components using compressed air.
4. Drain water from fuel system as follows:
 - a. Disconnect remote fuel hose from engine.
 - b. Remove drain plug from vapor separator and drain fuel/water. Reinstall plug after draining.
 - c. Remove the water separating fuel filter and empty contents.
5. Drain water from engine as follows:
 - a. Remove throttle plate assembly (4 bolts) and sponge water/debris out of air plenum.
 - b. Remove spark plugs from engine.
 - c. Rotate flywheel manually to blow out any water from the cylinders.



- d. Add approximately one ounce (30ml) of engine oil into each spark plug hole. Rotate the flywheel manually several times to distribute the oil in the cylinders. Reinstall spark plugs.
6. Drain water from the oil injection system as follows:
 - a. Remove remote oil hose (black without blue stripe) from pulse fitting on starboard side of engine.
 - b. Drain any water from hose and reconnect.
 - c. If water was present in hose, check for water in the remote oil tank. Drain tank if water is present.
7. Disassemble the engine starter motor and dry components.
8. Prime the oil injection pump as follows:
 - a. Fill the engine fuel system with fuel. Connect fuel hose to fuel lift pump (a).
 - b. Turn the ignition key switch to the "ON" position.




59217

NOTE: Audible click from the oil pump will tell you the pump is priming. It may take a few minutes for the pump to complete the priming process.

9. Attempt to start engine, using a fresh fuel source. If engine starts, it should be run for at least one hour to eliminate any water in engine.
10. If engine fails to start, determine cause (fuel, electrical or mechanical).



Model 240 HP Front View




59214

- | | |
|---|---|
| 1 - Throttle Plate Assembly | 10 - Vapor Separator Tank (VST) |
| 2 - 60 Ampere Alternator | 11 - Vapor Separator Drain Plug |
| 3 - Fuel Filter | 12 - SmartCraft Harness Connector |
| 4 - Fuel Lift Pump | 13 - Fuel Injector Harness Connector |
| 5 - Fuel Pressure Test Port | 14 - Fuel Tank/Oil Tank/Speedo Paddle
Wheel Harness Connector |
| 6 - High Pressure Fuel Hose 41-45 psi
(283-310 kPa) | 15 - Remote Oil Tank Pressure Hose |
| 7 - High Pressure Electric Fuel Pump
(Inside Vapor Separator) | 16 - Oil Pump |
| 8 - Electric Fuel Pump Harness Con-
nector | 17 - Starter Solenoid |
| 9 - 3 Amp Fuse for Fuel Lift Pump | 18 - Engine Harness Connector |
| | 19 - Air Temperature Sensor Connector |



Model 240 HP Starboard View




59229

- | | |
|---|--|
| 1 - Electronic Control Module | 12 - Powerhead/Jet Pump Flush Fitting |
| 2 - DDT Connector | 13 - Slave Solenoid/Positive(+) Battery Cable |
| 3 - Starter Motor | 14 - Main Power Relay |
| 4 - Starter Solenoid | 15 - Knock Sensor Harness Connector |
| 5 - Engine Harness Connector | 16 - Fuses (4) |
| 6 - Fuel Regulator Vacuum Hose | 17 - 3 Amp Fuseable Link Lead |
| 7 - Positive (+) Cable from Slave Solenoid | 18 - Starboard Knock Sensor |
| 8 - OIL/Fuel/Paddle Wheel Sensor Connector | 19 - Cyl. # 5 Ignition Coil |
| 9 - Oil Pump | 20 - Cyl. # 3 Ignition Coil |
| 10 - Remote Oil Tank Pressure Hose | 21 - Cyl. # 1 Ignition Coil |
| 11 - Negative (-) Battery Connector | 22 - Starboard Temperature Sensor |



Model 240 HP Port View




59213

- | | |
|---|--|
| 1 - Fuel Pressure Test Port | 14 - Oil Reservoir |
| 2 - High Pressure Fuel Hose 41-45 psi
(283-310 kPa) | 15 - Low Oil Switch |
| 3 - Throttle Plate Assembly | 16 - Pulse Fuel Pump |
| 4 - 60 Ampere Alternator | 17 - Idle Stop Screw |
| 5 - Port Temperature Sensor | 18 - 4 psi Check Valve |
| 6 - Water Bypass Hose | 19 - Inlet Oil Hose Filter |
| 7 - Exhaust Pipe Coolant Hose | 20 - Full Throttle Stop Screw |
| 8 - Bilge Siphon Hose | 21 - Fuel/Water Sensor |
| 9 - #2 Ignition Coil | 22 - Fuel/Water Separator |
| 10 - #4 Ignition Coil | 23 - Vapor Separator |
| 11 - #6 Ignition Coil | 24 - High Pressure Electric Fuel Pump
(Inside Vapor Separator) |
| 12 - Expansion Chamber Coolant Hose | 25 - Fuel Lift Electric Fuel Pump |
| 13 - Port Knock Sensor | 26 - Fuel Filter |
| | 27 - Fuel Pressure Regulator |



Model 240 HP Aft View




59210

- a** - #6 Ignition Coil
- b** - #4 Ignition Coil
- c** - #2 Cylinder
- d** - Port Temperature Sensor
- e** - Water Bypass Hose
- f** - Exhaust Pipe Coolant Hose
- g** - Bilge Suction Hose
- h** - Siphon Break
- i** - Starboard Temperature Sensor
- j** - #1 Cylinder
- k** - Expansion Chamber



Model 240 HP Top View




59211

- | | |
|--|---|
| 1 - Exhaust Pipe Coolant Hose | 15 - Air Temperature Sensor |
| 2 - Water Bypass Hose | 16 - MAP Sensor |
| 3 - Belt Tensioner | 17 - Throttle Plate Assembly |
| 4 - Tensioner Grease Fitting | 18 - Air Temp Sensor Connector |
| 5 - 60 Ampere Alternator | 19 - Starter Solenoid |
| 6 - Fuel Lift Pump Connector | 20 - Starter Motor |
| 7 - Fuel Lift Pump | 21 - Digital Diagnostic Terminal (DDT) Connector |
| 8 - Fuel Filter | 22 - Crank Position Sensor Connector |
| 9 - Fuel Inlet | 23 - Crank Position Sensor |
| 10 - VST Vent Hose Fitting | 24 - Engine Serial Number |
| 11 - Fuel Pressure Regulator | 25 - Exhaust Coolant Supply Hose |
| 12 - High Pressure Fuel Hose
41-45 psi (283-310 kPa) | |
| 13 - Throttle Position Sensor | |
| 14 - 3 Amp Fuseable Link Lead | |




Mercury Jet Pump Starboard View



- a** - Reverse Gate
- b** - Hull
- c** - Shift Cable Assembly
- d** - Water Intake
- e** - Trim Plate Assembly
- f** - Stator
- g** - Wear Ring

Mercury Jet Pump Port View



- a** - Steering Cable Assembly
- b** - Hull
- c** - Reverse Gate
- d** - Water Intake
- e** - Trim Plate Assembly
- f** - Forward Stop
- g** - Rudder