

## CHAPTER 6 LOWER UNIT

<b>LOWER UNIT</b> .....	6-1
REMOVING THE LOWER UNIT .....	6-1
REMOVING THE PROPELLER .....	6-3
CHECKING THE PROPELLER .....	6-3
INSTALLING THE PROPELLER .....	6-3
INSTALLING THE TRIM TAB .....	6-3
<b>WATER PUMP</b> .....	6-4
REMOVING THE WATER PUMP .....	6-4
CHECKING THE WATER PUMP HOUSING .....	6-5
CHECKING THE IMPELLER AND INSERT CARTRIDGE .....	6-5
CHECKING THE WOODRUFF KEY .....	6-5
INSTALLING THE IMPELLER AND WATER PUMP HOUSING .....	6-5
<b>SHIFT ROD</b> .....	6-6
REMOVING THE SHIFT ROD .....	6-6
<b>PROPELLER SHAFT HOUSING</b> .....	6-7
REMOVING THE PROPELLER SHAFT HOUSING .....	6-7
DISASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-8
DISASSEMBLING THE PROPELLER SHAFT .....	6-9
REMOVING THE PROPELLER SHAFT HOUSING .....	6-10
DISASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-10
CHECKING THE REVERSE GEAR .....	6-11
CHECKING THE BEARING .....	6-11
CHECKING THE PROPELLER SHAFT HOUSING .....	6-11
ASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-12
CHECKING THE DOG CLUTCH .....	6-13
CHECKING THE PROPELLER SHAFT .....	6-13
CHECKING THE SHIFT PLUNGER .....	6-13
CHECKING THE SPRING .....	6-13
<b>DRIVE SHAFT</b> .....	6-14
REMOVING THE DRIVE SHAFT .....	6-14
REMOVING THE DRIVE SHAFT .....	6-15
REMOVING THE DRIVE SHAFT BEARING .....	6-15
DISASSEMBLING THE FORWARD GEAR .....	6-15
CHECKING THE PINION AND FORWARD GEAR .....	6-16
CHECKING THE DRIVE SHAFT .....	6-16
CHECKING THE BEARINGS .....	6-16
ASSEMBLING THE FORWARD GEAR .....	6-16
INSTALLING THE DRIVE SHAFT BEARING .....	6-16
INSTALLING THE DRIVE SHAFT .....	6-17




---

<b>LOWER CASE</b> .....	6-18
DISASSEMBLING THE LOWER CASE .....	6-18
CHECKING THE DRIVE SHAFT SLEEVE .....	6-19
CHECKING THE NEEDLE BEARING .....	6-20
ASSEMBLING THE LOWER CASE .....	6-20
<b>SHIMMING</b> .....	6-21
SELECTING THE PINION SHIMS .....	6-22
SELECTING THE FORWARD GEAR SHIMS .....	6-24
SELECTING THE REVERSE GEAR SHIMS .....	6-26
<b>BACKLASH</b> .....	6-28
MEASURING THE FORWARD GEAR BACKLASH .....	6-28
MEASURING THE REVERSE GEAR BACKLASH .....	6-29

**LOWR**  **LOWER UNIT**

E

**LOWER UNIT**  
**REMOVING THE LOWER UNIT**




Step	Job/Part	Q'ty	Remarks
1	Cotter pin	1	<b>Not reusable</b>
2	Castle nut	1	
3	Washer	1	
4	Spacer	1	
5	Propeller	1	
6	Spacer	1	
7	Nut	1	
8	Shift connector	1	
9	Bolt (with washer)	1	
10	Trim tab	1	
11	Bolt	1	
12	Anode	1	
13	Screw	2	

Continued on next page.

**LOWR**  **LOWER UNIT**


E



Step	Job/Part	Q'ty	Remarks
14	Nut	2	
15	Water inlet cover 1	1	
16	Water inlet cover 2	1	
17	Gear oil level check screw	1	
18	Gasket	1	
19	Gear oil drain screw	1	
20	Gasket	1	
21	Bolt	4	
22	Lower unit	1	
23	Pin	2	

**LOWR**  **LOWER UNIT**

E



## REMOVING THE PROPELLER

Remove:

- Propeller


### **⚠ WARNING**

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

## CHECKING THE PROPELLER

Check:

- Blades
- Splines  
Bent/cracks/damage/wear → Replace.
- Bushing  
Slippage → Replace.



## INSTALLING THE PROPELLER

Install:


- Propeller

### **⚠ WARNING**

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

### **NOTE:**

If the groove in the propeller nut is not aligned with the cotter pin hole, tighten the nut further until they are aligned.



## INSTALLING THE TRIM TAB

Install:

- Trim tab


### **NOTE:**

- To ease installation, mark the original position of the trim tab.
- Steering load varies depending on the trim tab position as installed.



WATER PUMP

REMOVING THE WATER PUMP



Step	Job/Part	Q'ty	Remarks
1	Bolt	4	
2	Plate	1	
3	Water tube	1	
4	O-ring	1	<b>Not reusable</b>
5	O-ring	1	<b>Not reusable</b>
6	Water seal rubber	1	
7	Water pump housing	1	
8	Insert cartridge	1	
9	O-ring	1	<b>Not reusable</b>
10	Impeller	1	
11	Impeller plate	1	
12	Dowel pin	1	
13	Woodruff key	1	



## CHECKING THE WATER PUMP HOUSING

Check:

- Water pump housing  
Cracks/damage → Replace.

## CHECKING THE IMPELLER AND INSERT CARTRIDGE



Check:

- Impeller
- Insert cartridge  
Cracks/damage/wear → Replace.

## CHECKING THE WOODRUFF KEY

Check:

- Woodruff key  
Damage/wear → Replace.



## INSTALLING THE IMPELLER AND WATER PUMP HOUSING


Install:

- Impeller ①
- Insert cartridge ②
- Water pump housing ③

### NOTE:


- When installing the insert cartridge ②, align its projection with the hole in the water pump housing ③.
- When installing the water pump housing, turn the drive shaft clockwise.
- Apply Yamaha grease A (water resistant grease) on the impeller ①, the insert cartridge ②, and the water pump housing ③.

**SHIFT ROD**  
**REMOVING THE SHIFT ROD**




Step	Job/Part	Q'ty	Remarks
	Impeller plate		Refer to "WATER PUMP" on page 6-4.
1	Bolt	2	
2	Bracket	1	
3	Plate	1	
4	O-ring	1	<b>Not reusable</b>
5	Oil seal housing	1	
6	Lower casing packing	1	<b>Not reusable</b>
7	Dowel pin	1	
8	Shift rod	1	
9	Rubber seal	1	
10	Oil seal	2	





**PROPELLER SHAFT HOUSING**


**REMOVING THE PROPELLER SHAFT HOUSING**



Step	Job/Part	Q'ty	Remarks
	Gear oil		Refer to "CHANGING AND CHECKING THE GEAR OIL" on page 3-20.
	Shift rod assembly		Refer to "SHIFT ROD" on page 6-6.
1	Bolt	2	
2	Propeller shaft housing	1	
3	Washer	1	
4	Propeller shaft	1	



DISASSEMBLING THE PROPELLER SHAFT HOUSING




Step	Job/Part	Q'ty	Remarks
1	O-ring	1	<b>Not reusable</b>
2	O-ring	2	<b>Not reusable</b>
3	Reverse gear	1	
4	Reverse gear shim	*	
5	Ball bearing	1	
6	Oil seal	2	
7	Needle bearing	1	
8	Propeller shaft housing	1	
9	Washer	1	



\* As required



DISASSEMBLING THE PROPELLER SHAFT



Step	Job/Part	Q'ty	Remarks
1	Shift plunger	1	
2	Cross pin ring	1	
3	Cross pin	1	
4	Spring	1	
5	Dog clutch	1	
6	Propeller shaft	1	




### REMOVING THE PROPELLER SHAFT HOUSING

Remove:

- Propeller shaft housing



- Bearing housing puller claw ..... ①**  
90890-06564
- Stopper guide plate ..... ②**  
90890-06501
- Center bolt ..... ③**  
90890-06504




### DISASSEMBLING THE PROPELLER SHAFT HOUSING



1. Remove:

- Reverse gear



- Bearing separator ..... ①**  
90890-06534
- Stopper guide plate ..... ②**  
90890-06501
- Stopper guide stand ..... ③**  
90890-06538
- Bearing puller ass'y ..... ④**  
90890-06535






2. Remove:
- Ball bearing

	<b>Stopper guide plate</b> ..... ① <b>90890-06501</b>
	<b>Stopper guide stand</b> ..... ② <b>90890-06538</b>
	<b>Bearing puller ass'y</b> ..... ③ <b>90890-06535</b>

**NOTE:** \_\_\_\_\_  
Do not reuse the bearing. Always replace it with a new one.  
\_\_\_\_\_




3. Remove:
- Oil seal
  - Needle bearing

	<b>Driver rod L3</b> ..... ① <b>90890-06652</b>
	<b>Needle bearing attachment</b> ..... ② <b>90890-06615</b>

**CHECKING THE REVERSE GEAR**

- Check:
- Teeth
  - Dogs
- Damage/wear → Replace.




**CHECKING THE BEARING**

- Check:
- Bearing
- Pitting/rumbling → Replace.

**CHECKING THE PROPELLER SHAFT HOUSING**

- Check:
- Propeller shaft housing
- Cracks/damage → Replace.



**ASSEMBLING THE PROPELLER SHAFT HOUSING**

1. Install:
  - Needle bearing




**Needle bearing position.....a**  
**31.0 - 31.5 mm (1.22 - 1.24 in)**



**Driver rod-SS.....1**  
**90890-06604**  
**Needle bearing attachment.....2**  
**90890-06615**  
**Bearing depth plate.....3**  
**90890-06603**

**NOTE:** \_\_\_\_\_  
 Install the needle bearing with its manufacturer's marks (b) facing up. Apply Yamaha motor oil.



2. Install:
  - Oil seals







**Oil seal position.....a**  
**6.0 - 6.5 mm (0.24 - 0.26 in)**



**Driver rod L3.....1**  
**90890-06652**  
**Needle bearing attachment.....2**  
**90890-06611**

**CAUTION:** \_\_\_\_\_

It is essential that the oil seals are installed correctly (as shown in the illustration). If they are installed the wrong way round, oil or water will leak out.



3. Install:

- Reverse gear ①
- Reverse gear shim(s) ②
- Ball bearing ③
- Propeller shaft housing ④

**NOTE:**

- Before press-fitting the ball bearing, install the reverse gear shim(s).
- Install the ball bearing with its manufacturer's marks (a) facing the reverse gear.

**CAUTION:**

Place a suitable base under the gear to protect it from damages.

**CHECKING THE DOG CLUTCH**

Check:

- Dog clutch  
Damage/wear → Replace.

**CHECKING THE PROPELLER SHAFT**

Check:

- Propeller shaft  
Damage/wear → Replace.



**Maximum runout  
0.1 mm (0.004 in)**

**CHECKING THE SHIFT PLUNGER**

Check:


- Shift plunger  
Wear → Replace.

**CHECKING THE SPRING**

Check:


- Spring  
Weak → Replace.

**DRIVE SHAFT  
REMOVING THE DRIVE SHAFT**



Step	Job/Part	Q'ty	Remarks
	Propeller shaft housing		Refer to "PROPELLER SHAFT HOUSING" on page 6-7.
1	Pinion gear nut	1	
2	Pinion gear	1	
3	Drive shaft	1	
4	Forward gear	1	
5	Drive shaft bearing	1	





**REMOVING THE DRIVE SHAFT**


Remove:

- Pinion gear nut
- Drive shaft

	<b>Drive shaft holder 3 ..... ①</b> <b>90890-06517</b>
--	---

**Removing Steps**

- (1) Apply 12mm wrench on the pinion gear nut.
- (2) Support the lower case with rags to hold the wrench in position.
- (3) Turn the drive shaft holder ①.




**REMOVING THE DRIVE SHAFT BEARING**

Remove:

- Taper roller bearing

	<b>Bearing inner race attachment .... ①</b> <b>90890-06643</b>
--	---



**DISASSEMBLING THE FORWARD GEAR**

Remove:

- Taper roller bearing ①
- Forward gear ②

	<b>Bearing separator</b> <b>90890-06534</b>
--	--

**CAUTION:**


Place a suitable base on the gear axle to prevent damage to the top of the axle.



### CHECKING THE PINION AND FORWARD GEAR

Check:

- Teeth
  - Dogs
- Damage/wear → Replace.




### CHECKING THE DRIVE SHAFT

Check:

- Drive shaft
- Damage/wear → Replace.




**Maximum runout  
0.5 mm (0.020 in)**



### CHECKING THE BEARINGS

Check:

- Bearings
- Pitting/rumbling → Replace.




### ASSEMBLING THE FORWARD GEAR

Install:

- Forward gear
- Taper roller bearing



**Bearing inner race attachment .... ①  
90890-06644**




### INSTALLING THE DRIVE SHAFT BEARING

Install:

- Drive shaft bearing



**Bearing inner race attachment .... ①  
90890-06645**




**INSTALLING THE DRIVE SHAFT**

1. Install:
  - Forward gear  
(with the tapered roller bearing)
  - Drive shaft  
(with the tapered roller bearing)
  - Pinion gear

	<b>Drive shaft holder 3</b> ..... ① <b>90890-06517</b>
---	---

2. Tighten:
  - Pinion gear nut

	<b>Pinion gear nut</b> <b>50 N·m (5.0 kgf·m, 37 ft·lb)</b>
---	---




**Tightening steps**

- (1) Apply 12mm wrench on the pinion gear nut.
- (2) Support the lower case with rags to hold the wrench in position.
- (3) Turn the drive shaft holder ①.

**NOTE:** \_\_\_\_\_  
Tighten the pinion gear nut with the same tools that were used for removal.  
\_\_\_\_\_


**LOWER CASE**

**DISASSEMBLING THE LOWER CASE**




Step	Job/Part	Q'ty	Remarks
1	Drive shaft bearing outer race	1	
2	Pinion gear shim	*	
3	Drive shaft sleeve	1	
4	Needle bearing	1	
5	Tapered roller bearing outer race	1	
6	Forward gear shim	*	

\* As required




1. Remove:
  - Drive shaft bearing outer race
  - Pinion gear shim(s)

	<b>Stopper guide plate</b> .....① 90890-06501
	<b>Bearing puller ass'y</b> .....② 90890-06535
	<b>Stopper guide stand</b> .....③ 90890-06538




2. Remove:
  - Drive shaft needle bearing and sleeve

	<b>Driver rod L3</b> .....① 90890-06652
	<b>Needle bearing attachment</b> .....② 90890-06615




3. Remove:
  - Forward gear bearing outer race and shim(s)

	<b>Stopper guide plate</b> .....① 90890-06501
	<b>Bearing puller ass'y</b> .....② 90890-06535



**CHECKING THE DRIVE SHAFT SLEEVE**


- Check:
- Drive shaft sleeve  
Damage/wear → Replace.



**CHECKING THE NEEDLE BEARING**

Check:

- Needle bearing
- Pitting/rumbling → Replace.




**ASSEMBLING THE LOWER CASE**

1. Install:

- Forward gear shim(s) ①
- Tapered roller bearing outer race ②

	<b>Bearing outer race attachment</b> <b>90890-06622</b> <b>Driver rod LL</b> <b>90890-06605</b>
--	--




2. Install:

- Drive shaft needle bearing

	<b>Depth <sup>a</sup></b> <b>185.0 - 186.0 mm (7.28 - 7.32 in)</b>
--	---

	<b>Needle bearing attachment .....①</b> <b>90890-06615</b> <b>Driver rod SL .....②</b> <b>90890-06602</b> <b>Bearing depth plate .....③</b> <b>90890-06603</b>
--	---

**NOTE:** \_\_\_\_\_  
 Install the drive shaft needle bearing with the manufacturer's marks facing up.



3. Install:


- Pinion gear shim(s) <sup>a</sup>
- Drive shaft bearing outer race <sup>b</sup>




	<b>Driver rod LS .....①</b> <b>90890-06606</b> <b>Bearing outer race attachment....②</b> <b>90890-06628</b>
--	--

SHIMMING

**NOTE:**

- There is no need to select shims when reassembling with the original case and inner part(s).
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).





**SELECTING THE PINION SHIMS**

**NOTE:** \_\_\_\_\_  
 Select the shim thickness (T3) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T3)

**Selecting steps**

(1) Install the pinion height gauge, drive shaft and bearing (with bearing race).

	<b>Pinion height gauge</b> ..... ① <b>90890-06702</b>
	<b>Drive shaft holder 3</b> ..... ② <b>90890-06517</b>


**NOTE:** \_\_\_\_\_

- Attach the pinion height gauge to the drive shaft so that the shaft is at the center of the hole.
- After the wing nuts contact the fixing plate, tighten them another 1/4 of a turn.

(2) Install the pinion gear and pinion gear nut.

	<b>Pinion gear nut</b> <b>50 N•m (5.0 kgf•m, 37 ft•lb)</b>
---	---


(3) Measure (M).

	<b>Digital caliper</b> <b>90890-06704</b>
---	--

**NOTE:** \_\_\_\_\_

- Measure the clearance between the pinion height gauge and the pinion, as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M).
- When using the digital caliper, be sure to place it at right angles to the pinion. Otherwise, measurement will be incorrect.





(4) Calculate the pinion gear shim thickness (T3).



**Pinion gear shim thickness (T3) =**  
**M - 27 mm - P/100 mm**

**NOTE:**

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01 mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then add the "P" value to the measurement.

**Example:**

If M is "28.30 mm" and "P" is "+5", then:

$$T3 = 28.30 \text{ mm} - 27 \text{ mm} - (+5)/100 \text{ mm}$$

$$= 1.3 \text{ mm} - 0.05 \text{ mm}$$

$$= 1.25 \text{ mm (0.049 in)}$$

If M is "28.24 mm" and "P" is "-3", then:

$$T3 = 28.24 \text{ mm} - 27 \text{ mm} - (-3)/100 \text{ mm}$$

$$= 1.24 \text{ mm} + 0.03 \text{ mm}$$


$$= 1.27 \text{ mm (0.05 in)}$$

(5) Select the pinion gear shim(s) (T3).

Calculated numeral at 1/100th place		Using shim
more than	or less	
1.10	1.20	1.2
1.20	1.30	1.3
1.30	1.40	1.4
1.40	1.50	1.5
1.50	1.60	1.6
1.60	1.70	0.7, 1.0
1.70	1.83	0.7, 1.1



**Available shim thickness**  
**0.7, 1.0, 1.1, 1.2, 1.3, 1.4, 1.5 and 1.6 mm**




**SELECTING THE FORWARD GEAR SHIMS**

**NOTE:** \_\_\_\_\_  
 Select the shim thickness (T1) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T1)


**Selecting steps**

(1) Measure (M).





	<b>Shimming plate</b> ..... ① 90890-06701
	<b>Digital caliper</b> ..... ② 90890-06704

- NOTE:** \_\_\_\_\_
- Turn the tapered roller bearing outer race two or three times so that the rollers seat. Then, measure the height of the bearing, as shown.
  - Perform the same measurement at three points on the tapered roller bearing outer race.
  - Find the average of the measurements (M).
  - When using the digital caliper, be sure to place it at right angles to the shimming plate. Otherwise, measurement will be incorrect.



(2) Calculate the forward gear shim thickness (T1).



	<b>Forward gear shim thickness (T1) =</b> <b>17.5 mm + F/100 mm - M</b>
---	--

- NOTE:** \_\_\_\_\_
- "F" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01 mm units. If the "F" mark is missing or unreadable, assume an "F" value of "0", and check the backlash when the unit is assembled.
  - If the "F" mark is negative (-), then subtract the "F" value from the measurement.



Example:


If M is "16.25 mm" and "F" is "+4", then:


$$\begin{aligned}
 T1 &= 17.5 \text{ mm} + (+4)/100 \text{ mm} - 16.25 \text{ mm} \\
 &= 17.5 \text{ mm} + 0.04 \text{ mm} - 16.25 \text{ mm} \\
 &= 1.29 \text{ mm (0.051 in)}
 \end{aligned}$$

If M is "16.26 mm" and "F" is "-3", then:

$$\begin{aligned}
 T1 &= 17.5 \text{ mm} + (-3)/100 \text{ mm} - 16.26 \text{ mm} \\
 &= 17.5 \text{ mm} - 0.03 \text{ mm} - 16.26 \text{ mm} \\
 &= 1.21 \text{ mm (0.048 in)}
 \end{aligned}$$

(3) Select the forward gear shim(s) (T1).

Calculated numeral at 1/100th place		Using shim
more than	or less	
<b>1.00</b>	<b>1.10</b>	<b>1.0</b>
<b>1.10</b>	<b>1.20</b>	<b>1.1</b>
<b>1.20</b>	<b>1.30</b>	<b>1.2</b>
<b>1.30</b>	<b>1.40</b>	<b>1.3</b>
<b>1.40</b>	<b>1.50</b>	<b>1.4</b>
 <b>Available shim thickness</b> <b>1.0, 1.1, 1.2, 1.3 and 1.4 mm</b>		




**SELECTING THE REVERSE GEAR SHIMS**

**NOTE:** \_\_\_\_\_  
 Select the shim thickness (T2) the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T2)

**Selecting steps**

(1) Measure (M2).





	Shimming plate ..... ① 90890-06701
	Digital caliper ..... ② 90890-06704

**NOTE:** \_\_\_\_\_

- Measure the height of the gear as shown.
- Perform the same measurement at three points on the gear.
- Find the average of the measurements (M2).
- When using the digital caliper, be sure to place it at right angles to the shimming plate. Otherwise, measurement will be incorrect.

(2) Calculate the reverse gear shim thickness (T2).



	<b>Reverse gear shim thickness (T2) =</b> <b>80 mm + R/100 - M2</b>
---	--

**NOTE:** \_\_\_\_\_

- "R" is the deviation of the lower case dimension from standard. It is stamped on the anode mounting surface of the lower case in 0.01 mm units. If the "R" mark is missing or unreadable, assume a "R" value of "0", and check the backlash when the unit is assembled.
- If the "R" mark is negative (-), then subtract the "R" value from the measurement.



Example:


If M2 is "78.79 mm" and "R" is "+5", then:

$$\begin{aligned}
 T2 &= 80 \text{ mm} + (+5)/100 \text{ mm} - 78.79 \text{ mm} \\
 &= 80 \text{ mm} + 0.05 \text{ mm} - 78.79 \text{ mm} \\
 &= 1.26 \text{ mm (0.050 in)}
 \end{aligned}$$

If M2 is "78.75 mm" and "R" is "-3", then:

$$\begin{aligned}
 T2 &= 80 \text{ mm} + (-3)/100 \text{ mm} - 78.75 \text{ mm} \\
 &= 80 \text{ mm} - 0.03 \text{ mm} - 78.75 \text{ mm} \\
 &= 1.22 \text{ mm (0.048 in)}
 \end{aligned}$$

(3) Select the reverse gear shim(s) (T2).


Calculated numeral at 1/100th place		Using shim
more than	or less	
<b>1.00</b>	<b>1.10</b>	<b>1.0</b>
<b>1.10</b>	<b>1.20</b>	<b>1.1</b>
<b>1.20</b>	<b>1.30</b>	<b>1.2</b>
<b>1.30</b>	<b>1.32</b>	<b>1.3</b>
 <b>Available shim thickness 1.0, 1.1, 1.2 and 1.3 mm</b>		



## BACKLASH

**NOTE:**

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion gear may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion gear may be too low.





### MEASURING THE FORWARD GEAR BACKLASH

1. Measure:
  - Forward gear backlash
 Out of specification → Adjust.


	<b>Forward gear backlash</b> 0.31 - 0.72 mm (0.012 - 0.028 in)
--	---

#### Measuring steps

- (1) Set the shift rod into the neutral position.
- (2) Install the propeller shaft housing puller so it pushes against the propeller shaft.



	<b>Bearing housing puller claw</b> ..... ① 90890-06564
	<b>Stopper guide plate</b> ..... ② 90890-06501
	<b>Center bolt</b> ..... ③ 90890-06504
	<b>Center bolt</b> 5 N·m (0.5 kgf·m, 3.7 ft·lb)



(3) Install the backlash indicator onto the drive shaft (16mm (0.63 in) diameter).

	<b>Backlash indicator</b> ..... (4) <b>90890-06706</b>
--	---

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	<b>Magnet base plate</b> ..... (5) <b>90890-07003</b>
	<b>Dial gauge set</b> ..... (6) <b>90890-01252</b>
	<b>Magnet base</b> ..... (7) <b>90890-06705</b>

(5) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

**2. Adjust:**

- Forward gear backlash  
Remove or add shim(s).

	Forward gear backlash	Shim thickness
	Less than 0.31 mm (0.012 in)	To be decreased by $(0.52 - M) \times 0.49$
	More than 0.72 mm (0.028 in)	To be increased by $(M - 0.52) \times 0.49$
<b>Available shim thickness:</b> 1.0, 1.1, 1.2, 1.3 and 1.4 mm		


M : Measurement

**MEASURING THE REVERSE GEAR BACKLASH**




**1. Measure:**

- Reverse gear backlash  
Out of specification → Adjust.

	<b>Reverse gear backlash</b> <b>0.93 - 1.65 mm (0.037 - 0.065 in)</b>
--	--

**LOWR**  **BACKLASH**

E



**Measuring steps**


- (1) Set the shift rod into the neutral position.
- (2) Load the reverse gear by installing the propeller without the collar ①, and then tighten the propeller nut.

	<b>Propeller nut</b> <b>5 N·m (0.5 kgf·m, 3.7 ft·lb)</b>
---	---

- (3) Install the backlash indicator onto the drive shaft (16 mm (0.63 in) diameter).

	<b>Backlash indicator</b> ..... ② <b>90890-06706</b>
---	---


- (4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	<b>Magnet base plate</b> ..... ③ <b>90890-07003</b>
	<b>Dial gauge set</b> ..... ④ <b>90890-01252</b>
	<b>Magnet base</b> ..... ⑤ <b>90890-06705</b>

- (5) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

**2. Adjust:**

- Reverse gear backlash  
Remove or add shim(s).

	<b>Reverse gear backlash</b>	<b>Shim thickness</b>
	<b>Less than</b> <b>0.93 mm (0.037 in)</b>	<b>To be decreased by</b> <b>(1.29 - M) × 0.49</b>
	<b>More than</b> <b>1.65 mm (0.065 in)</b>	<b>To be increased by</b> <b>(M - 1.29) × 0.49</b>
<b>Available shim thickness</b> <b>1.0, 1.1, 1.2 and 1.3 mm</b>		

M : Measurement